MATIC DIAGRAM



RS-766US-2



1) S1-1～S1-8, S2-1～S2-8 is RECORDING & PLAYBACK changing SWITCH.
2) S3-1～S3-4 is EQUALIZER changing SWITCH.
3) S4-1～S4-2 is STOP SWITCH.
4) S5 is POWER CHANGING SWITCH. (now at 250V)
5) S6 is SHUTT-OFF MYCHRO SWITCH.
6) S7 is POWER SWITCH.

MATSUSHITA ELECTRIC CORP. OF AMERICA
Pan-Am Bldg., 200 Park Ave., New York, N. Y. 10017

Printed in Japan SQX-95
(03692-D) Ⓑ

MODEL SE-9000HG

SCHEMATIC DIAGRAM



MATSUSHITA ELECTRIC

Pan-Am Bldg., 200 Park Ave